



ITEM NO.	PART NO.	DESCRIPTION	QTY
01	HP211-01	Pump Housing	1
02	X	Oil Filter	1
03	X	Ring	2
04	HP211-04	Tie Rod	1
05	HP211-05	Reservoir	1
06	HP212-06	Tail Base	1
07	X	O-Ring	1
08	X	Latch Ring	1
09	X	Handle Latch	1
10	X	Brass Washer	1
11	X	Nut	1
12	X	O-Ring	1
13	X	Air Release Screw	1
14	X	Vent Screw	1
15	RV	Steel Ball	5
16	X	Screw	3
17	X	O-Ring	1
18	X	Back-Up Ring	1
19	HP211-19	H.P. Piston	1
20	X	Snap Ring	1
21	X	O-Ring	1
22	X	Back-Up Ring	1
23	HP227-21	L.P. Piston	1
24	HP232-23	Yoke	1
25	X	Yoke Pin	1
26	X	Piston Pin	1
27	X	Retaining Ring	3
28	HP211-28	Handle	1
29	X	Handle Grip	1
30	X	Screw	2
31	HP212-31	Yoke Base	1
32	X	Spring Pin	1
33	X	Oil Seal	1
34	X	Washer	1
35	RV	Release Nut	1
36	RV	Release Valve Screw	1
37	RV	Release Knob	1
38	RV	Screw	1
39	X	Steel Ball	2
40	X	Inlet Ball Spring	2
41	X	Steel Ball	2
42	X	Outlet Ball Spring	2
43	X	Set Screw	2
44	X	Steel Ball	2
45	X	Spring End Cap	2
46	X	L.P. Spring	1
47	X	H.P. Spring	1
48	X	O-Ring	2
49	X	Overload Cover Screw	2
50	X	Cap	2
51	X	Spring	1
52	HP227-52	Release Valve Assy	1

NOTE: ITEMS MARKED "RV" ONLY AVAILABLE AS RELIEF VALVE ASSEMBLY. ITEM 52.
NOTE: ITEMS MARKED "X" SUPPLIED IN KIT HP211TP1-K ONLY

IMPORTANT
WHEN ORDERING SPARES YOU MUST STATE THE FULL PART NUMBER AND THE
PRODUCT SERIAL NUMBER - FROM THE LABEL
TO PROTECT YOUR WARRANTY ALWAYS USE GENUINE HI-FORCE PARTS