


ITEM NO.	PART NO.	DESCRIPTION	QTY	ITEM NO.	PART NO.	DESCRIPTION	QTY
01	HP232-01	Pump Housing	1	46	X	O-Ring	1
02	X	Oil Filter	1	47	RV	Knob Screw	1
03	X	Ring	2	48	RV	Release Valve Screw	1
04	HP232-04	Tie Rod	1	49	X	Spring	2
05	HP232-05	Reservoir	1	50	X	Overload Cover Screw	1
06	HP232-06	Tail Base	1	51	X	Long Separator Spring	1
07	X	O-Ring	1	52	X	Cone	1
08	X	Hook Ring	1	53	X	Cone Seat	1
09	X	Fixing Hook	1	56	X	Brass Washer	1
10	X	Screw	2	57	X	Nut	1
11	X	Steel Ball	4	58	HP227-52	Release Valve Assy	1
12	X	Set Screw	3				
13	X	O-Ring	1				
14	X	Back-Up Ring	1				
15	HP227-17	Pump Piston	1				
16	X	Snap Ring	1				
17	X	O-Ring	1				
18	X	Back-Up Ring	1				
19	HP227-21	Pump Piston	1				
20	X	Piston Pin	1				
21	X	Yoke Pin	1				
22	X	Retaining Ring	3				
23	HP232-23	Yoke	1				
24	HP232-24	Handle	1				
25	X	Handle Grip	1				
26	HP232-26	Yoke Base	1				
27	X	Roll Pin	1				
28	X	Oil Seal	1				
29	X	Washer	1				
30	RV	Release Nut	1				
31	RV	Pin	1				
32	RV	Release Knob	1				
33	X	Steel Ball	2				
34	X	Steel Ball	2				
35	X	Spring	2				
36	X	Washer	2				
37	X	Valve Cover Screw	2				
38	X	Steel Ball	1				
39	X	Spring End Cap	1				
40	X	O-Ring	2				
41	X	Overload Cover Screw	1				
42	X	Cap	2				
43	X	Short Separator Spring	1				
44	X	Air Release Screw	1				
45	X	Vent Screw	1				



NOTE: ITEMS MARKED "RV" ONLY AVAILABLE AS RELEASE VALVE ASSEMBLY. ITEM 58

NOTE: ITEMS MARKED "X" SUPPLIED IN KIT HP232TP1-K ONLY

IMPORTANT

WHEN ORDERING SPARES YOU MUST STATE THE FULL PART NUMBER AND THE PRODUCT SERIAL NUMBER - FROM THE LABEL TO PROTECT YOUR WARRANTY ALWAYS USE GENUINE HI-FORCE PARTS