


ITEM NO.	PART NO.	DESCRIPTION	QTY	ITEM NO.	PART NO.	DESCRIPTION	QTY
01	XHP2800-01	Pump Housing	1	51	XHP2800-51	Setting Screw Seat	1
02	X	Spring	1	52	X	Steel Ball	1
03	X	Ball Seat	1	53	X	Pin	1
04	X	Steel Ball	1	54	X	Spring	1
05	X	O-Ring	2	55	X	Steel Ball	1
06	X	Washer	2	56	RV	Release Nut	1
07	XHP2800-07	High Pressure Valve	1	57	RV	O-Ring	1
08	XHP2800-08	Inlet Valve	1	58	RV	Release Valve Screw	1
09	XHP2800-09	Tie Rod	1	59	RV	Screw	1
10	X	O-Ring	2	60	RV	Nut	1
11	XHP2800-11	Reservoir	1	61	RV	Release Knob	1
12	XHP2800-12	Tail Base	1	62	RV	Screw	1
13	XHP2800-13	Hook Ring	1	63	XHP2800-63	Base Plate	1
14	XHP2800-14	Fixing Hook	1	64	X	Screw	2
15	X	Nut	1	65	X	Plug	2
16	X	O-Ring	1	66	XHP2800-66	Release Valve Assy	1
17	X	Breather Nut	1				
18	X	Seal	1				
19	X	Breather	1				
20	X	Copper Washer	3				
21	X	Fasten Nut	1				
22	X	O-Ring	1				
23	X	Back-Up Ring	1				
24	XHP2800-24	Piston Housing	1				
25	X	O-Ring	1				
26	XHP2800-26	Piston Pump	1				
27	X	O-Ring	1				
28	X	Back-Up Ring	1				
29	XHP2800-29	Piston Pump	1				
30	X	Snap Ring	1				
31	XHP2800-31	Upper Piston	1				
32	XHP2800-32	Yoke	1				
33	X	Piston Pin	1				
34	X	Yoke Pin	1				
35	X	E-Ring	3				
36	XHP2800-36	Handle	1				
37	X	Handle Grip	1				
38	XHP2800-38	Yoke Base	1				
39	X	Roll Pin	1				
40	X	Screw	1				
41	X	Bolt Plug	1				
42	X	Steel Ball	1				
43	X	Spring End Cap	1				
44	X	Long Separator Spring	1				
45	X	O-Ring	2				
46	XHP2800-46	Overload Cover Screw	2				
47	X	Cap	2				
48	X	Cone Seat	1				
49	X	Cone	1				
50	X	Spring	1				

NOTE: ITEMS MARKED "RV" ONLY AVAILABLE
AS RELEASE VALVE ASSEMBLY.ITEM 66

NOTE: ITEMS MARKED "X" SUPPLIED IN KIT
XHP2800TP2-K ONLY



IMPORTANT

WHEN ORDERING SPARES YOU MUST STATE THE FULL PART NUMBER AND THE
PRODUCT SERIAL NUMBER - FROM THE LABEL
TO PROTECT YOUR WARRANTY ALWAYS USE GENUINE HI-FORCE PARTS